






From External USB connector



To Teensy USB connector




Power Switch



Low voltage LED adjustment



R1  
1kΩ



D1  
1N4001



Low battery LED  
Red (633nm)



R2  
330Ω



Power/USB Schematic

Project Game-o-Tron 3000

Filename Got3000\_power.fzz

Rev 1.0

Date 14 Sep 2015 21:26:43

Sheet 1/1